
225 AMP, 120/240 VAC, 1PHASE, 3 WIRE, 42 CIRCUIT PANELBOARD WITH 200 AMP, 2 POLE MAIN BREAKER WITH 10,000 AIC AT 240 VAC IN A NEMA 1 ENCLOSURE. INCLUDE SEPERATE GROUND BAR KITS. ALL BRANCH BREAKERS SHALL BE BOLT-ON TYPE WITH 10,000 AIC AT 120/240 VAC. PANELBOARD SHALL BE SQUARE D CAT NO. NQOD42L225CU WITH NQODQB MAIN BREAKER KIT & QBL22200 MAIN BREAKER IN A NEMA 1 ENLCOSURE OR APPROVED EQUAL.

- PANELBOARD BUS SHALL BE COPPER. NEUTRAL BUS SHALL BE COPPER. EQUIPMENT GROUND BARS SHALL BE COPPER.
- 2. INCLUDE ENGRAVED PHENOLIC LEGEND PLATE LABELED "VAULT PANEL, 120/240 VAC, 1 PHASE, 3 WIRE".
- 3. FEEDER BREAKER FOR FUEL SYSTEM LOAD CENTER SHALL BE 30 AMP, 1-POLE WITH SWITCHED NEUTRAL & SHUNT TRIP FEATURE.



			FUEL	FACILITY	LOAD	CENTER	SCHEDULE	
CKT #	#	DUTY		SIZE				 ~~~~
1		FUEL FACILITY EQUIPMENT		20A 1P	T-			
2				SWN	سلم الم			
3		FUEL FACILITY EQUIPMENT		20A 1P	T	<u></u>		
4				SWN	ما الما			
5		BLANK				L		
6		BLANK				Ľ		
					111	<u> </u>		
					5/1	V GND_		

100 AMP, 120/240 VAC, 1 PHASE, 3 WIRE, 6 CIRCUIT LOAD CENTER WITH MAIN LUGS, IN A NEMA 1 ENCLOSURE, SQUARE D CLASS 1130, CAT. NO. QO612L100DSCU OR APPROVED EQUAL. INCLUDE EQUIPMENT GROUND BAR KIT. BRANCH BREAKERS SHALL HAVE 10,000 AIC RATING AT 120/240 VAC. LOAD CENTER BUS SHALL BE COPPER.

- SWN INDICATES BRANCH BREAKER WITH SWITCHED NEUTRAL FEATURE.
- LOAD CENTER SHALL BE CONNECTED FOR 120 VAC, 1 PHASE, 2-WIRE OPERATION. ONE BUS PHASE WILL NOT BE POWERED.
- PROVIDE LEGEND PLATE FOR LOAD CENTER LABELED "FUEL SYSTEM PANEL, 120 VAC, 1PH, 2W".

NOTES FOR FAN CONTROL SCHEMATIC

- 1. GROUND WIRES REQUIRED BUT NOT SHOWN FOR CLARITY.
- 2. ALL WIRING SHALL BE #12 THWN MINIMUM.
- 3. PROVIDE A NEMA 1 ENCLOSURE SIZED AS REQUIRED TO INSTALL THE CONTACTOR, HOA SELECTOR SWITCH &
- 4. PROVIDE LEGEND PLATE FOR THE CONTACTOR AND FRACTIONAL HP MOTOR STARTER IDENTIFYING THE LOAD SERVED AND THE POWER SOURCE.
- 5. VERIFY MOTOR HORSEPOWERS AND FULL LOAD AMPS WITH THE RESPECTIVE MANUFACTURER. CONTRACTOR SHALL COORDINATE MOTOR CIRCUIT BREAKER, CONTACTOR, FRACTIONAL HP STARTER, OVERLOADS, WIRE SIZES, CONDUIT SIZES, ETC. FOR THE RESPECTIVE EQUIPMENT FURNISHED, PER NEC & MANUFACTURER'S RECOMMENDATIONS. COORDINATE FAN & LOUVER INSTALLATION WITH BUILDING MFR.
- 6. INTAKE LOUVERS SHALL OPEN AND EXHAUST FAN SHALL OPERATE WHEN SPACE TEMP EXCEEDS 85'F (ADJUSTABLE). EXHAUST FAN SHALL OPERATE ONLY WHEN DAMPER HAS PROVED "OPEN". IN MANUAL MODE DAMPER SHALL REMAIN OPEN AND FAN SHALL RUN CONTINUOUSLY.

LEGEND


- 1 120VAC, NEMA SIZE 0 (MINIMUM), 1 POLE, FULL VOLTAGE CONTACTOR IN A NEMA 1 ENCLOSURE, SQUARE D CLASS 8502, TYPE SBG5V02 OR APPROVED EQUAL. INCLUDE H-O-A SELECTOR SWITCH WITH CONTACTOR.
- 2 FRACTIONAL HORSEPOWER MOTOR MANUAL STARTER, SQUARE D MANUAL STARTER WITH HANDLE/GUARD/LOCK OFF, IN NEMA 1 ENCLOSURE CLASS 2510, TYPE FG5 OR APPROVED EQUAL. INCLUDE MELTING ALLOY TYPE THERMAL OVERLOADS SIZED AS REQUIRED TO PROTECT THE RESPECTIVE MOTOR. 120VAC MOTORS SHALL HAVE SINGLE POLE STARTERS.

TR005

TRI-TOWNSHIP AIRPORT SAVANNA, CARROLL COUNT ILLINOIS

HANSON

CONSTRUCT NEW VAULT



EXHAUST FAN CONTROL SCHEMATIC