

## NOTES:

- 1. THE AGGREGATE FOR TEMPORARY ACCESS SHALL BE PLACED IMMEDIATELY FOLLOWING THE MILLING OPERATION.
- 2. THE AGGREGATE FOR TEMPORARY ACCESS SHALL BE REMOVED IMMEDIATELY PRIOR TO PLACING POLYMERIZED LEVELING BINDER.
- 3. ALL WORK SHALL BE INCIDENTAL TO "AGGREGATE FOR TEMPORARY ACCESS".

## AGGREGATE FOR TEMPORARY ACCESS DETAIL

(NOT TO SCALE)

ILLINOIS PROFESSIONAL DESIGN FIRM NO. 184-002235

ph 708.672,4994

fax 708.672.3739

CHECKED BY: RWM

DATE: SEPTEMBER 4, 2009