



Note:
Replace existing rivets with 7/8" H.S. Bolts.
Ream existing holes to 15/16" (unless otherwise noted).
All Stiffeners are tight fit to match existing.
Work this Sheet with Table on Sheet 32.

I:\Projects\4015550\4015550-0201-90-CAD Models and Sheets\04_CJ_Bridge\SDI\081905-64H28-026-51stiffener.dgn