

-UTILITY OR STORM SEWER TRENCH

\* SEE TYPICAL SECTIONS FOR THICKNESS AND MATERIALS

## NOTES:

1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.

SEE NOTE 1.

2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

			٠.
Γ	REVISIONS		Γ
	NAME	DATE	
	R. SHAH	10/25/94	
	R. SHAH	01/14/95	
	R. SHAH	03/23/95	
	R. SHAH	04/24/95	
	A. HOUSEH	03/15/96	
L	A. ABBAS	03/21/97	
	A. ABBAS	01/20/98	
	ART ABBAS	04/27/98	
	R. BORO	01/01/07	
	R. BORO	09/04/07	L

ILLINOIS DEPARTMENT OF TRANSPORTATION

PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT

SCALE: VERT. NONE

CHECKED BY

BD400-04 (BD-22)