

8. Install ground wells 4'-6" as measured from centerline of the HMLT to centerline of the well. Adjust service pad reinforcement to

miss wells.

(HMLT not shown for clarity)

BOWMAN, BARRETT & ASSOCIATES INC.
CONSTRUTING PROFINERS
B RAST RANBOLPH STREET SUITE 2656 CHICAGO, ILLINOIS EAST
100 NO. 144

DRAWN BY: CHECKED BY:

SCALE: NOT TO SCALE

DATE: October 29, 2004