

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

REVISIONS	
NAME	DATE
R. SHAH	10/25/9
R. SHAH	01/14/95
R, SHAH	03/23/9
R. SHAH	04/24/9
A. HOUSEH	03/15/90
A. ABBAS	03/21/9
A. ABBAS	01/20/9
ART ABBAS	04/27/9
R BORO	01/01/0

ILLINOIS DEPARTMENT OF TRANSPORTATION

PAVEMENT PATCHING FOR HMA SURFACED PAVEMENT

SCALE: VERT. NO

DRAWN BY CHECKED BY

BD400-04 (BD-22)

.07 DATE = 3/5/2007 LE NAME = Ki\distatd\bd22.dgn 07 SCALE = 50.000 '/ IN.