



## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

REVISIONS		ILLINOIS DEPARTMENT OF TRANSPORTATION
NAME	DATE	ILLINOIS DEPARTMENT OF TRANSPORTATION
R. SHAH	10/25/94	
R. SHAH	01/14/95	
R. SHAH	03/23/95	PAVEMENT PATCHING FOR
R. SHAH	04/24/95	HMA SURFACED
A. HOUSEH	03/15/96	
A. ABBAS	03/21/97	PAVEMENT
A. ABBAS	01/20/98	
ART ABBAS	04/27/98	CALLE VERT. NOVE

98 SCALE: VERT. NONE HORIZ. PLOT DATE: 1/24/2008

CHECKED BY
BD400-04 (BD-22)

BD400-04 (BD-22)

REVISION DATE: 01/01/07

PLOT DATE = 1/24/2008 FILE NAME = P:\DistDetail-Willow\bd22.dc LOT SCALE = 52.941 / IN. SCEN NAME = A.M.