
c:BprojectsB74144dBshtdetails_74144.dgn *DATF*

SECTION 322 SHELBY 33


** PLACE THE FIRST ARROW EVEN WITH THE BEGINNING OF THE TURN BAY. PLACE ANOTHER ARROW 18' BACK FROM THE STOP BAR. IF REQUIRED, ADD ADDITIONAL ARROWS TO MAINTAIN A MAXIMUM OF 80' SPACING.



TYPICAL BI-DIRECTIONAL TURN LANE MARKINGS

(SHOWING TRANSITION TO EXCLUSIVE LEFT TURN LANE)

- 1. NO LESS THAN 2 ARROWS SHALL BE USED.
- 2. TAPER RATES, LANE WIDTHS, AND STORAGE LENGTHS AS SHOWN ON THE PLANS.
- 3. AVOID PLACING BI-DIRECTIONAL ARROWS IN INTERSECTIONS.
- 4. BI-DIRECTIONAL ARROWS SHALL BE SPACED A MAXIMUM OF 250'.



NOT TO SCALE ILLINOIS DEPARTMENT OF TRANSPORTATION

TYPICAL APPLICATION OF **PAVEMENT MARKINGS** SHEET 2 OF 2

SCALE: VERT.