

• LA GRANGE WETLAND BANK •• D-6 WETLAND MITIGATION NO. 1

BALES PLACED ON EDGE

O. 3m (1') MIN.
SEE NOTE 1

O. 675m (2'-3") MIN. - SEE NOTE 1

(BOTH SIDES SAME HEIGHT)

EMBEDMENT


O. 6 m

(2'-0")

& VAR.

HAY OR STRAW BALE TEMPORARY DITCH CHECK

(TYPICAL & SEE GENERAL NOTES FOR SUBSTITUTION TO FLUSH RIPRAP DITCH CHECK)



NOTE 1: BALES SHALL EXTEND FAR ENOUGH UP THE SLOPES TO ALLOW 0.3m (1') OVERTOPPING TO AVOID ERODING AROUND THE EDGES OF THE BALES.

NOTE 2: RIPRAP SHALL EXTEND FAR ENOUGH UP THE SLOPES TO ALLOW 0.3m (1') OVERTOPPING TO AVOID ERODING AROUND THE EDGES OF THE RIPRAP.

NOTE 3: ENDS SHALL BE TIED INTO SLOPES.

LEGEND FOR STORM WATER POLLUTION PREVENTION PLAN SYMBOL ITEM AGGREGATE (EROSION CONTROL) [STONE DUMPED RIPRAP DITCH CHECKS: Height = 0.6m (2')] TEMPORARY DITCH CHECKS (HAY OR STRAW BALE DITCH CHECKS OR APPROVED SUBSTITUTION) \oplus INLET PIPE PROTECTION (1&PP) (HAY OR STRAW BALE DITCH CHECKS OR APPROVED SUBSTITUTION) EROSION CONTROL FENCE EARTH EXCAVATION FOR EROSION CONTROL (SEDIMENT BASINS) PRESERVE EXISTING TREES, WOODLANDS, AND UNDERSTORY (OUTSIDE CONSTRUCTION LIMITS) ITEM PLACED AT BEGINNING OF * [TEM * CONSTRUCTION (Requirement) ITEM PLACED AS DIRECTED BY [TEM ENGINEER (When required by situation) DIRECTION OF OVERLAND FLOW GENERAL NOTES: All items shall be constructed as shown on this sheet, on Standard 280001, and as directed by the Englineer.

The symbology on the STORM WATER POLLUTION PREVENTION PLAN sheets does not represent the size or quantity of bales, for number of bales refer to details and notes shown on this sheet and/or as directed by the Engineer.

THE CONTRACTOR SHALL INSTALL DITCH CHECKS AS DIRECTED BY THE ENGINEER. IF THE ENGINEER ELECTS TO UTILIZE FLUSH RIPRAP DITCH CHECKS IN LIEU OF TEMPORARY DITCH CHECKS AS SHOWN ON THE FOLLOWING PLAN SHEETS, THE SPACING SHOULD BE DOUBLED.

REVISIONS
NAME DATE
CAD Symbol 2
JCN MAR2004

STORM WATER POLLUTION
PREVENTION PLAN

SCALE: VERT. DRAWN BY CADD
HORIZ. DATE: APRIL 5, 1999 CHECKED BY JCN

SWPPLAN

c:\projects\d650305\swpplan.dgn 2/9/2005 3:49:12 PM kentbd

STRINGS OR

HAY OR STRAW BALE

(TYPICAL ELEVATION)

WIRES