

LAYOUT	TEH	12/22/08
DRAWN	DAP	12/23/08
REVIEWED	TEH	-

The Unconfined Compressive Strength (UCS) Failure Mode is indicated by (B-Bulge, S-Shear, P-Pneumometer, E-Estimated) Abbreviations W.O.H - Sampler Advanced By Weight of Hammer, W.O.P - Advanced by Weight of Pipe, B.S. - Before Seating The SPT (N value) is the sum of the last two blow values in each sampling zone (AASHTO T206) BBS, from 137 (Rev. 8-99)

The Unconfined Compressive Strength (UCS) Failure Mode is indicated by (B-Bulge, S-Shear, P-Penetrometer, E-Estimated)
Abbreviations W.O.H - Sampler Advanced By Weight of Hammer, W.O.P - Advanced by Weight of Pipe, B.S. - Before Seating
The SPT (N value) is the sum of the last two blow values in each sampling zone (AASHTO T206) BSE, from 137 (Rev. 8-99)

 HANSON Hanson Professional Services Inc.	JOB NO. 07S2026	SHEET NO. 27 29 SHEETS	F.A. RTE.	SECTION	COUNTY	TOTAL SHEETS	SHEET NO.
	DATE 03/27/09		614	144(B-1, B-2)	Mason	351	134
	CONTRACT NO. 72A76						
			FED. ROAD DIST. NO.	ILLINOIS	FED. AID PROJECT		