

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

| REVISIONS | NAME | DATE | R. SHAH | 10/25/94 | R. SHAH | 10/25/94 | R. SHAH | 01/14/95 | R. SHAH | 03/23/95 | R. SHAH | 04/24/95 | A. HOUSEH | 03/15/96 | A. ABBAS | 03/21/97 | A. ABBAS | 03/21/97 | A. ABBAS | 01/20/98 | ART ABBAS | 04/27/98 | R. BORO | 01/01/07 | SCALE: | HORIZ. | NONE | DRAWN BY | PLOT DATE: 4/11/2007 | CHECKED BY

RIZ. CHECKED BY

BD400-04 (BD-22)

PLOT DATE = 4/11/2007 FILE NAME = CINDocuments and Settings/qureshiya\Desktop\60 PLOT SCALE = 60.800 ' / IN,