

## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

## SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

DESIGNED - R. SHAH ISER NAME = gaglianobt PAVEMENT PATCHING FOR DRAWN REVISED A. ABBAS 04-27-98 STATE OF ILLINOIS A\distatd\22x34\bd22.dor 10-00111-00-LS СООК HMA SURFACED PAVEMENT PLOT SCALE = 50.000 '/ IN-CHECKED REVISED R. BORO 01-01-07 **DEPARTMENT OF TRANSPORTATION** BD400-04 (BD-22) PLOT DATE = 1/4/2008 10-25-94 SHEET NO. 1 OF 1 SHEETS STA. TO STA.