

1. Place form brace system on completed reinforcement level; back from the finished fabric face a distance of  $I_3$  to  $I_2$  the geotextile reinforcement spacing.

- 2. Position fabric so that the required geotextile re-embedment length extends over the top of the form brace and the design reinforcement width is placed with no slack against the previous level.
- 3. Compact select fill material in lifts to final lift height, create (±3'') depression in zone where re-embedment length will be located and place additional height of compacted select fill against form brace.
- 4. Fold geotextile re-embedment length back over form brace into zone where depression was made in select fill and place additional select fill (±3'') to embed geotextile and bring to final lift height.
- 5. Pull form brace outward allowing geotextile face to slightly readjust to form tight round face level with plan reinforcement spacing.

## TEMPORARY GEOTEXTILE WALL CONSTRUCTION SEQUENCE

The geotextile soil reinforcement shall have a minimum allowable tensile strength (T min.) of 20 lb./in. as determined by the procedure described in the Special Provision. The computations supporting the determination of (T min.) shall be submitted

Aggregate Subgrade 12" and PGE, Subgrade are billed with the

AINING WALL	F.A.P. RTE			SEC	TION			COUNTY	TOTAL SHEETS	SHEET
54 STA. 100 + 00.15	870		534R-B					DUPAGE	53	34
								CONTRACT	NO. (	SOM83
S13 SHEETS	DATE:	AUGUST	03,	2012	ILLINOIS	FED.	AID	PROJECT		