

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS OTHERWISE SHOWN.

DESIGNED - R. SHAH **PAVEMENT PATCHING FOR** STATE OF ILLINOIS \projects\d134708\d134708aa.dg 16-2-1-K-RS HMA SURFACED PAVEMENT COOK 31 19 CONTRACT NO. 60E26 CHECKED REVISED - R. BORO 01-01-07 **DEPARTMENT OF TRANSPORTATION** PLOT SCALE = 50.0000 '/ IN. BD400-04 (BD-22) PLOT DATE = 3/27/2008 DATE REVISED - R. BORO 09-04-07 SCALE: NONE SHEET NO. 1 OF 1 SHEETS STA.