



## NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 300 (12) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE SPECIAL PROVISION "PATCHING WITH BITUMINOUS OVERLAY REMOVAL"

## SEQUENCE OF CONSTRUCTION

- 1, REMOVE THE EXISTING BITUMINOUS MATERIAL OVER THE AREA TO BE PATCHED.
- 2, REMOVE AND REPLACE FULL DEPTH PATCHES
- 3, REPLACE BITUMINOUS MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN MILLIMETERS (INCHES) UNLESS OTHERWISE SHOWN.

ILLINOIS DEPARTMENT OF TRANSPORTATION

**PAVEMENT PATCHING FOR** BITUMINOUS SURFACED **PAVEMENT** 

CHECKED BY

BD400-04 (BD-22)

03/15/96 03/21/97 01/20/98

o:\projects\diststd\bd22.dgn LV=35,63 Friday October 18,2002 @ 09:04:45 AM