

HVAC ELECTRICAL NOTES

- WALL-MOUNTED UNIT HEATERS UH-1 & UH-2, 10KW, 480V, 3-PHASE. HEATER SHALL INCLUDE INTEGRAL POWER DISCONNECT SWITCH AND BE SUITABLE FOR USE WITH EXTERNAL THERMOSTAT AND EXTERNAL 120V CONTROL. WIRING:
 - THREE #10 THWN (480V), ONE #12 GROUND IN 3/4" CONDUIT TO PANEL #1
 - TWO #12 THWN (CONTROL), ONE #12 GROUND IN 3/4" CONDUIT TO THERMOSTAT.
- ROOF MOUNTED EXHAUST FAN EF-1, 3/4 HP, 120V. WIRE TO COOLING THERMOSTAT FOR AUTO-OFF-ON CONTROL.
- SUPPLY LOUVER SL-1 & SL-2 WITH MOTORIZED DAMPER. WIRE TO COOLING THERMOSTAT FOR AUTO-ON-OFF CONTROL.
- UNIT HEATER WALL-MOUNTED THERMOSTAT, 120V, SPST, CLOSE ON FALLING TEMPERATURE. WIRING: - TWO #12 THWN (120V), ONE #12 GROUND TO PANEL #2 (GROUIT # AS SHOWN).
 - TWO #12 THWN (120V CONTROL), ONE #12 GROUND TO UNIT HEATER UH-1.

 - TWO #12 THWN (120V CONTROL), ONE #12 GROUND TO UNIT HEATER UH-2.
- EXHAUST FAN WALL-MOUNTED THERMOSTAT, 120V, SPDT, CLOSE ON RISING TEMPERATURE, WITH "AUTO-OFF-ON" SUBBASE. WIRING:
 - TWO #12 THWN (120V), ONE #12 GROUND TO PANEL #2 (CIRCUIT # AS SHOWN).
 - TWO #12 THWN (120V), ONE #12 GROUND TO EF-1.
 - TWO #12 THWN (120V), ONE #12 GROUND TO SL-1.
 - TWO #12 THWN (120V), ONE #12 GROUND TO SL-2.
- FRACTIONAL HORSEPOWER STARTER TO BE USED AS DISCONNECT FOR LOUVER MOTOR. PROVIDE THERMAL OVERLOADS SIZED FOR MOTORS PER MANUFACTURER INSTRUCTIONS. INTERIOR WALL MOUNT

UN051

Base_Vault X-FIr Plan

K:\ChampaignAp\1105903\Draw\Sheets FILE: 1105903—E—5206.dwg

PLOT DATE: 4/30/2012 3:53 PM

REVISIONS NUMBER BY

> THIS BAR IS EQUAL TO 2 AT FULL SCALE (34X22).

> > **ECTRICAL PLAN**

LIGHTING VAULT 핍 VAULT HVAC **NEW AIRFIELD**

E≪

CONSULTING

AIRPORT OF ILLINOIS


WILLARD /

WDP DESIGN BY: DRAWN BY: CMT JEH CHECKED BY: JEH APPROVED BY: JOB No: 11059-03

> IL. PROJ. NO. CMI-4100 AIP PROJ. NO. 3-17-0016-XX


SHEET 50 OF 60 SHEETS

NEW HVAC EQUIPMENT PLAN VIEW SCALE: N.T.S.



EXHAUST FAN WIRING DIAGRAM

- WALL MOUNTED THERMOSTAT WITH "AUTO-OFF-ON" SUBBASE.
- 2 FRACTIONAL HORSEPOWER STARTER NEAR SUPPLY LOUVER.
- 3 EXHAUST FAN.
- 4) SUPPLY LOUVER DAMPER MOTOR.
- DISCONNECT AT EXHAUST FAN.



HEATER THERMOSTAT WIRING

UNIT HEATERS AND ACCESSORIES, EXHAUST FANS AND ACCESSORIES, SUPPLY LOUVERS AND ACCESSORIES, THERMOSTATS, FAN "ON-AUTO" TOGGLE SWITCH, FRACTIONAL HORSEPOWER STARTERS, ETC., SHALL BE FURNISHED COMPLETE BY HVAC EQUIPMENT SUPPLIER.