

Item	Unit	Total
Elastomeric Bearing Assembly, Type I	Each	40
Jack & Remove Existing Bearings	Each	40
Anchor Bolts. I"	Each	40
Anchor Bolts, 1 ¹ 4"	Each	40