

District 2 Horizontal & Vertical Control Setup

1 The following outlines the steps for setting up the files to be used with the District 2 "HorzVertControl.mvba" to create the HVC tables and alignment descriptions.

1) Copy the *"HorzVertControl.mvba"* and *"Horizontal_and_Vertical_Control.pdf"* files to *".....\IDOT_CONNECT\Configuration\Organization-Civil\IDOT_Standards\Macros"* folder.




2) Copy the *"CogoAlignmentDescriptionASCII.xsl"* and *"D2_StationOffsetNorthingEastingElevationFeature_CSV.xsl"* files to *".....\IDOT_CONNECT\Configuration\Organization-Civil\IDOT_Standards\Reports"* folder.



HARD COPIES UNCONTROLLED

3) Copy the *"District2_Text Favorites_Text Styles_Dimension Styles.dgnlib"* file to *".....\IDOT_CONNECT\Configuration\Workspaces\IDOTCAD CONNECT\Standards\DgnLib\Feature Definitions"* folder.



Where **.....** is the drive location of the "IDOT_CONNECT" folder.

4) The *"HorzVertControl.mvba"* application is activated by using the following key-in command:

vba run [HorzVertControl]modStart.Start

5) Refer to the *"Horizontal_and_Vertical_Control.pdf"* file for the steps to use this application.

HARD COPIES UNCONTROLLED