

## SENSOR ASSEMBLY INSTALLATION PROCEDURE:

- 1. USING A CHALK LINE, MARK THE SENSOR TRENCH OUTLINE ON THE PAVEMENT. SEE SYSTEM LAYOUT DRAWING FOR SENSOR LOCATIONS.
- 2. SAW CUT AROUND THE TRENCH PERIMETER TO A DEPTH OF  $1\frac{1}{2}$ ".
- 3. SAW CUT THE  $\frac{3}{8}$ "  $\times$  1" DEPTH. SENSOR CABLE SLOT THE THE EDGE OF THE PAVEMENT.
- 4. REMOBE EXISTING PAVEMENT TO A DEPTH OF  $1^{1}\!/_{2}$ " WITHIN THE SAW CUT TRENCH PERIMETER.
- 5. THOROUGHLY CLEAN THE TRENCH OF ALL DEBRIS, DUST, ETC.
- 6. PLACE SENSOR ASSEMBLY IN THE TRENCH. ADJUST THE #10-32 LEVELING SCREWS UNTIL THE TOP OF THE SENSOR ASSEMBLY IS EVEN WITH THE PAVEMENT SURFACE. (NO HIGHER THAN 1/16")
- 7. THOROUGHLY MIX LARGE CAN OF ENCAPSULANT.

- 8. ADD HARDENER & MIX THOROUGHLY.
- 9. POUR ENCAPSULANT AROUND SENSOR TRYING NOT TO DISTURB SENSOR.
- 10. 3 TO 5 POUND WEIGHT MAY HAVE TO BE USED TO STOP FLOATING.
- 11. FILL TRENCH WITH MIXTURE UNTIL FLUSH WITH THE SURFACE OF PAVEMENT. TROWEL AS REQUIRED.
- 12. LET EPOXY CURE UNTIL HARD.
- 13. GRIND PERIMETERS IF NEEDED TO REMOVE HIGH OR ROUGH SPOTS.

NOTE: SENSOR CAN BE BENT SLIGHTLY TO CONFORM TO ROADWAY.

REFERENCE: INSTALLATION MANUAL #1050527

## **DETECTOR LOOP DETAILS**

886-1

₽º FILE	NAME =	USER NAME = 560kar	DESIGNED -	REVISED -		·	F.A. SECTION C	OUNTY TOTAL SHEET
j. IIVCr	.Crystal Lake\DKLBC\Ø81Ø68-PoacoRd\CAD	D-SURVEY\DRAWINGS\DGNS\PH2-sheets\081068-D	TORAWN-	REVISED -	STATE OF ILLINOIS	IDOT DISTRICT 3 DETAILS	5369 06-00172-00-WR D	eKALB 64 53
NSE v		PLOT SCALE = \$SCALE\$	CHECKED -	REVISED -	DEPARTMENT OF TRANSPORTATION			ONTRACT NO. 87465
SIA S60 560		PLOT DATE = 10/28/2010	DATE -	REVISED -		SCALE: NONE SHEET NO. OF SHEETS STA. TO STA.	FED. ROAD DIST. NO. 3   ILLINOIS FED. AID PROJECT M-5017 (043)	

COPYRIGHT © 2008, BY BAXTER & WOODMAN, NG. STATE OF ILLINOIS - PROFESSIONAL DESIGN FIRM LICENSE NO. - 18-4-00121 - EXPIRES 4/30/2011