

SUGGESTED SEQUENCE OF OPERATIONS

INSTALL WIDE LOAD SIGNING AND ERECT SIGNALS AND SIGNING AS REQUIRED FOR STAGE I AND STAGE II CONDITIONS IN ACCORDANCE WITH THE SPECIAL PROVISION FOR TRAFFIC CONTROL AND PROTECTION STANDARD 701201 AND COVER UNTIL BARRIER PLACEMENT BEGINS.

PLACE TEMPORARY PAVEMENT MARKINGS ON THE WEST SIDE FOR STAGE I TRAFFIC USING TRAFFIC CONTROL AND PROTECTION STANDARD 701321 AND REMOVE EXISTING PAVEMENT MARKINGS BETWEEN TEMPORARY STOP BARS.

SAW CUT EXISTING BRIDGE DECK ALONG THE STAGE REMOVAL LINE AND DRIVE TEMPORARY SHEET PILING.

IMPLEMENT STAGE I TRAFFIC CONTROL BY PLACING TEMPORARY BRIDGE RAIL, TEMPORARY CONCRETE BARRIERS, IMPACT ATTENUATORS AND BARRELS TO ROUTE TRAFFIC OVER THE WEST LANE OF THE EXISTING BRIDGE.

REMOVE EAST PORTION OF THE EXISTING BRIDGE DECK, EXISTING PIERS, ABUTMENT BACK WALLS, UPPER PORTION OF WINGWALLS AND GUARDRAIL.

CONSTRUCT THE EAST (STAGE I) PORTION OF THE BRIDGE ABUTMENTS, WINGWALLS, PIERS, DECK, GRANULAR BACKFILL, BRIDGE APPROACH PAVEMENTS, TRAFFIC BARRIER TERMINALS, AND GUARD RAIL. REMOVE EXISTING SHOULDERS AND PLACE BITUMINOUS SHOULDERS SUPERPAVE FOR STAGE II TRAFFIC.

BITUMINOUS CONCRETE BASE COURSE WIDENING, SUPERPAVE 10"

BITUMINOUS SHOULDERS SUPERPAVE, 8" THICKNESS

BITUMINOUS SHOULDERS SUPERPAVE, 10" THICKNESS

INSTALL TEMPORARY PAVEMENT MARKINGS ON THE WEST SIDE

REMOVE PARTIAL EXISTING SHOULDER FOR STAGE I TRAFFIC AND PLACE BITUMINOUS CONCRETE BASE COURSE WIDENING, SUPERPAVE 10".

PRE STAGE I

STAGE I



